
### **Device Layout**

# LED Indicator & Sensor -





### Recent Apps button

**Hard Keys** 

· Press to see recently used apps.

### Home button

 $\boldsymbol{\cdot}$  From any apps or screens, press to return to the Home screen.

### Back button

• Press to go back to the previous screen, or to close a dialog box, options menu, notification panel, etc.

### Function button

Press to run the preset function or action.
 Set on EmKit - Program Buttons.

# **Removing Battery Cover**



1. Slide the battery cover lock to the unlock position.





2. Lift up the battery cover to open.

### · AC Plug · Battery

· LCD Protection Film

· AC/DC Adapter (5V 2A) · USB Type-C Cable

- · Quick Start Guide
- · Wrist Lanyard
- Stylus

MOST POWERFUL RUGGED ANDROID DEVICE REDEFINING MOBILITY

# Quick start guide

PM90

# **Inserting Battery**



1. Insert battery from the top first, then push the bottom.



2. Insert the battery cover from the top first and then press down the bottom.

### Installing SIM-SAM/Micro SD Card

### Installing SIM-SAM card/Micro SD card

You must insert your SIM card to make phone calls. Please turn the device off before inserting or removing the SIM card.

- 1. Remove the Battery Cover and Battery.
- 2. Lift up the SIM rubber.
- 3. Insert the SIM-SAM/Micro SD card into the slot, with the gold contact facing down. Make sure that it is inserted correctly
- 4. To remove the card, repeat step1 and step2, then gently slide it out of the slot.



### <Caution>

- Your device only supports Micro SIM cards. Do not attempt to insert other SIM types such as "Nano", since this may cause damage to your device. If you have to use different SIM card types, please use a "SIM adaptor".
- The device supports storage extension up to 32GB with micro SD card.

# Charging the PM90



- 1. Insert USB cable into the adapter and connect to the country plug to charge.

  2. Insert USB type C connector to the PM90.

  3. LED indicator will display charging status.

Steady Red	Battery is charging or the battery level is low		
Blinking Red	Battery level is critically low		
Steady Green	Battery is fully charged		
Standard Battery	2,900mAh 3.85V		
Extended Battery	5,800mAh 3.85V		
Charging Time Standard Battery: About 4 hours Extended Battery: About 6 hours			

### <Caution>

- Always use a standard charger and cable from Point Mobile.
   Other chargers and cables may damage the PM90.
- You can also charge the device with optional accessories such as single or dual slot cradles.

· For more details of product information and user guide, please refer to our website (www.pointmobile.com)

### Accessories

### **Standard Accessories**

# 5V 2A AC/DC Adapter





### Standard Battery (2,900mAh)



LCD Protection Film



USB Type-C Cable



Wrist Lanyard



Stylus Pen

# Accessories **Optional Accessories**



SEC (Single-Slot Ethernet Cradle)

4SBC (4-Slot Battery Charge) 4SC (4-Slot Cradle)





Extended Battery (5,800mAh)



### **Getting Started**

### Turning the device on and off

- Press the Power button to turn on the device. After a few seconds, device will turn on.
- Press and hold the Power button for a few seconds and tap 'Power off' on the screen options.

### Set up

Start with setting the input language, google account, GPS, etc., when the device is turned on for the first time.

### Home screen items



### **Notification icons**

Status icons

LTE+▲

×

Ť

•

\*₩

ì

Ē 8

Ô

×	Missed call	p	New SMS or MMS message
~	New Email	0-	Connected to VPN network
Ö	Upcoming event	Image: Control of the	Alarm is set
8	Preparing SD card	<b>=</b>	SD card removed, unexpectedly
ψ	OTG device connected		Screenshot captured
<u> </u>	File uploaded	<u>+</u>	File downloaded
	File copied		
[11]	Scanner turned on		
•	There are more notifications		Other input method available

**Status & Notification Icons** 

TE+ (LTE CA) connecte

Data communication

Strong signal

Veak signal

onnection issue

tspot enabled

Battery is partially draine

Battery is very low

 $\checkmark$ 

Δ

**(** 

.₩

•••

1

Google, Android, Google Play and other marks are trademarks of Google LLC.

# Reset the PM90

Press and hold the Power button for at least 8 seconds to power off or hold it longer to restart.

### **Factory reset**

Follow the process by tapping the next button to complete factory reset.

### Settings → System → Reset options → Erase all data (factory reset) → RESET PHONE → ERASE EVERYTHING







<Caution>



Please note, all apps and data in the internal storage will be deleted and restored to factory settings and this process cannot be undone.

# Support

ARS: +82-1800-3010 Fax: +82-2-3397-7872 Address: 9F Kabul Great Valley, 32, Digital-ro 9-gil, Geumcheon-gu, Seoul, Korea 08512

Website: https://www.pointmobile.com/ E-mail: pm\_support@pointmobile.co.kr

### For more information

Please refer to the user manual for more information on safety & regulations of device and accessories.

# Certification

Equipment name: Mobile computer Model: PM90 Trade name of certified: Point Mobile Co., Ltd. Manufacturer: Point Mobile

For more certificate information go to Settings → About phone → Certificates

# **Specifications**

Item	Specifications
Model	PM90
Operating System	Android 9.0 or higher version (GMS certified)
Software	Tools and Demos
Micro-Processor	Qualcomm <sup>®</sup> Snapdragon, Octa-core, 2.2GHz
Memory(RAM/ROM)	4GB RAM+64GB Flash/3GB RAM+32GB Flash (Optional
Memory Extension	User accessible Micro SD memory card slot.
Display	5.0* Wideviewing angle IPS (FHD 720 X 1280 pixels)
Keypad	9 physical kys (all programmable except the power key)
Audio	Two built-in microphones, one speakr, and a headset jack.
Weight	With standard batt. 272g / 9.59oz With extended batt. 322g / 11.36oz
Wi-Fi	802.11 a/b/g/n/ac/d/h/i/k/r/v
UMTS / HSPDA / HSUPA	EDGE/GPRS/GSM:900/1800/850/1900 WCDMA: B1/2/4/\$/6/8/19 LTE FDD: B1/2/3/4/5/7/8/12/13/14/17/19/25/26/20/28 LTE TDD: B38/839/B40/41
Bluetooth	Bluetooth v5.0, class 1
GPS	Qualcomm GPS (Phone SKU)
NFC/RFID	13.56MHz
USB	USB 3.0 Type-C/OTG
Battery	Li-ion battery: 2,900mAh, 3.85V 5,800mAh, 3.85V
Adapter	Output: 5V / 2A, Input: 100-240V~50/60Hz
Battery Capacity / Charging Time	Capacity: 2,900mAh – About 4 hours 5,800mAh – About 6 hours
Operating Temperature	-20°C to 60°C
Rain/Dust Protection	IP67

# **Safety information**

Please note your phone is battery-embedded design with removable battery and battery cover. Unauthorized personnel are strictly prohibited from disassembling the phone. Make sure to use only the power adapter (5V 2A Output AC/DC) that came with

In case your phone does not work as expected, you are strongly recommended to restart it by pressing and holding the power button for at least 8 seconds until the startup screen appears. If your phone has encountered a serious error and cannot be recovered, you should reset your phone to factory settings by using the menu, either "Backup & Reset", or "Factory Reset".

### www.sar-tick.com

# Body-worn operation

This device was tested for typical body-worn operations with the front & back of worn operations with the front & back of the phone kept 0.59 inches (1.5 cm) between the user's body and the front & back of the phone. A minimum separation distance of 0.59 inches (1.5 cm) must be maintained between the user's body and the front & back of the phone. Any belt clips, holsters, and similar accessories containing metallic components may not be used. Body-worn accessories that cannot maintain 0.59 inches (1.5 cm) separation distance between the user's body and the front & back of the phone, and have not been tested for typical body-worn operations should be avoided.



# Protect your hearing

To prevent possible hearing damage, do not listen at high volume levels for long periods. Exercise caution when holding your device near your ear while the loudspeaker is in use.