Wireless Barcode Scanner User's Manual

V9.8.3

Introduction

Wireless barcode scanner transfer the data to computer via receiver.

If scanner & receiver need to re-pair, scan the "Pairing Function".

LED Description

Red

- Charging: Light on
- Charging finished: Light off

Green

- Slow flash: Scanner is not connected to receiver or USB
- Flash: Scanner is connected to receiver or USB
- Quick flash: Entering the pairing mode
- Flash once : Data upload successfully

Buzzer Description

- Long & high beep: Switch on
- Twice high & low beeps: Switch off, setup code or decoding success
- A medium long & high beep: good scan or pairing up receiver
- Three continuous short beeps: Alarm prompt

Default Setting

Note: With (*) is the factory default.

Data Transfer Mode

*Immediate

Automatic Storage

Note: Automatic storage mode. Data is automatically saved in scanner when exceed communication distance, scan the "Upload all data" code to complete the data transfer.

Inventory

Note: Inventory mode, the scanned barcode will be automatically saved in scanner. If the data need to be viewed or uploaded, then scan the "Upload all data" code to complete the data transfer.

Upload all data

Clear all data

Note: Clear all data can be effective under Inventory mode & Automatic Storage mode.

Display stored data

USB Interface Type

*USB-HID

USB-COM

Note:The USB interface type of both scanner and receiver will be changed.

Below is for Bluetooth scanner only.
Device named: BLE-HID

Wireless Bluetooth Setting

*2. 4G

Bluetooth

Bluetooth serial port

Note: Scan the bluetooth code change to bluetooth mode. When the scanner is restored, for bluetooth mode scan the code again.

Bluetooth HID transmission rate

Fast

*Medium

Low

IOS show/hide the Keyboard (Under Bluetooth mode)

Show or Hide

Pairing Function

Note: Scan this code, scanner will enter the automatic pairing mode for 1 minute, then re-insert the receiver. There will be a sound heard when pairing successfully.

Bluetooth HID Pairing

For Bluetooth pairing setting, search by Bluetooth device

Battery Display

Display battery capacity

Note: Percentage display

Sound Settings

Mute

*High

Medium

Low

MCU voice

*Sensor voice

Sleeping Settings (2 Types)

Different Sleeping time choices:

Immediate sleep

10s

30s

*1min

2min

5min

10min

30min

Language Settings

*USA

Germany

France

Italy

Canada

Spain

Brazil

Sweden

Portugal

Belgium

Turkey-F

Turkey-Q

Universal language

Terminator

NONE

*CR

LF

TAB

CR/LF

Display Version

Software version