

# Advice for cleaning CILICO Mobile Computer

## What you need

### Disinfectant



1. Isopropyl alcohol or ethanol (70%-75%)
2. Software paper tissue or microfiber towel

## Follow these steps



1. Spray the alcohol onto a soft paper tissue or microfiber towel



2. Wipe the device to clean it thoroughly, including screen and buttons, scan window



3. Let the residue dry for a minute or two and your device is clean and good to go.

### Caution!

**DO NOT** spray the cleaning liquid directly onto your device.

**Always** use a fresh soft tissue or microfiber towel.

**Iodide** is not recommended.

**DO NOT** use aggressive cleaning agents or abrasive pads to clean our device

